

This item is guaranteed against defects in materials and workmanship for three months from the time of purchase. Please contact the manufacturer if a problem develops with your Un-Spoolit hand cart.



8 Anvil Street,
Kitchener, ON
N2P 1X6
www.p3tek.com
519-895-6998



Instructions on safe and proper use of the Un-Spoolit hand cart

Important safeguards

- ?? Do **not** use if the equipment is damaged in any way
- ?? Use this equipment only for the transport and dispensing of product from spools
- ?? Do **not** attempt to dispense product from damaged spools
- ?? Avoid uneven floors and obstacles while moving loaded Un-Spoolit hand cart
- ?? Use the strap and hook assembly for the tipping and transport of larger spools
- ?? Do **not** load equipment beyond the published weight limits
- ?? Un-Spoolit hand cart must be on level, stable surface when in the horizontal position
- ?? Do **not** stand on any part of the Un-Spoolit hand cart while stationary or in operation
- ?? Exercise caution around moving parts to avoid pinching fingers

Correct use

1. The target spool to be transported must be laying flat on it's side. See fig 1.



Fig 1

2: The front plate of the Un-Spoolit hand cart must be slid under the spool to be dispensed. Manual positioning of the spool is sometimes necessary. Make sure the spool is resting against the rollers. Secure the strap hook through the centre hole of the spool if the diameter of the spool exceeds 16 inches (40cm).

3: The Un-Spoolit hand cart must be braced with your foot against the axel before tipping the load to prevent the Un-Spoolit hand cart from rolling backwards.

4: Pushing the Un-Spoolit hand cart is preferred to dragging the Un-Spoolit hand cart, for the increased visibility it provides.

5: When the selected location for product dispensing is reached, the Un-Spoolit hand cart must be rotated to the horizontal position. The preferred method of dispensing is to pull the product from the top of the spool. See fig 2.



Fig 2

6: Disengage the strap hook before dispensing product.

7: Pull off the desired amount of product, taking extra precaution towards the end of a spool. Often the product is secured through the centre shaft of the spool. Dislodging of the empty spool from the Un-Spoolit hand cart may occur if caution is not exercised.

8: After the product has been cut, any excess product must be rolled up and secured to the spool. The spool must be re-positioned firmly against the bottom plate of the Un-Spoolit hand cart. See fig 3. If the strap hook was used, it must be reattached.



Fig 3

9: Rotate the Un-Spoolit hand cart to position for transporting the spool to it's storage destination using the same methods referenced in step 4.

10: Detach the strap hook if necessary and slide the front plate of the Un-Spoolit hand cart from under the spool.

Store the Un-Spoolit hand cart in a location away from pedestrian traffic or forklift operating areas.